



# Shenzhen Xtooltech Co., Ltd

## DFPeugeot Function List V10.63

### Tips and Instructions:

- \* This feature is new.
- ✓ This feature is supported.
- ✗ This feature is not supported.
- ※ This feature is partially supported.

Model	System Name	ECU	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
206	Engine	DCN2	✓	✓	✓	✓		
206	Engine	EDC15C2	✓	✓	✓	✓	✓	
206	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206	Engine	EDC17C10_BR2	✓	✓	✓	✓	✓	S0037,S0036
206	Engine	J34P	✓	✓	✓	✓	✓	S0034
206	Engine	ME745	✓	✓	✓	✓	✓	S0034
206	Engine	N6A_ME749_BIO_FLEX	✓	✓	✓	✓	✓	S0034

206	Engine	NFU_OR_N6A_ME749	✓	✓	✓	✓	✓	S0034
206	Engine	V343	✓	✓	✓	✓	✓	
206	Engine	V34_3	✓	✓	✓	✓	✓	
206	Engine	ME744	✓	✓	✓	✓	✓	S0034
206	Diesel fuel additive control unit		✓	✓	✓	✓		
206	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	
206	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206	Gearbox ECU	Auto Gearbox AL4	✓	✓	✓	✓	✓	
206	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓	✓		
206	Air Conditioning		✓	✓	✓	✓		
206	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206	Radio	RDE	✓	✓	✓	✓		

206	Instrument panel		✓	✓	✓	✓	✓	
206	Switch module at the steering wheel		✓	✓	✓	✓		
206	Alarm		✓	✓	✓	✓		
206	On board navigation system		✓	✓	✓	✓		
206	Driving school mode		✓	✓	✓	✓		
206	Rain/brightness sensor		✓	✓	✓	✓		
206	Power steering		✓	✓	✓	✓		
206 MUX	Engine	DCN2	✓	✓	✓	✓		
206 MUX	Engine	EDC15C2	✓	✓	✓	✓	✓	
206 MUX	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC17C10_BR2	✓	✓	✓	✓	✓	S0037,S0036
206 MUX	Engine	J34P	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	ME745	✓	✓	✓	✓	✓	S0034

206 MUX	Engine	N6A_ME749_BIO_FLEX	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	NFU_OR_N6A_ME749	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	V343	✓	✓	✓	✓	✓	
206 MUX	Engine	V34_3	✓	✓	✓	✓	✓	
206 MUX	Engine	ME744	✓	✓	✓	✓	✓	S0034
206 MUX	Diesel fuel additive control unit		✓	✓	✓	✓		
206 MUX	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	S0039,S0035
206 MUX	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206 MUX	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206 MUX	Gearbox ECU	Auto Gearbox AL4	✓	✓	✓	✓		
206 MUX	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓	✓		
206 MUX	Airbag ECU	Airbag and seatbelts	✓	✓	✓	✓		
206 MUX	Airbag ECU	Left side airbag	✓	✓	✓	✓		
206 MUX	Airbag ECU	Right side airbag	✓	✓	✓	✓		

206 MUX	Air Conditioning		✓	✓	✓	✓		
206 MUX	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206 MUX	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206 MUX	Radio	RDE filament	✓	✓	✓	✓		
206 MUX	Instrument panel		✓	✓	✓	✓	✓	
206 MUX	Alarm		✓	✓	✓	✓		
206 MUX	On board navigation system		✓	✓	✓	✓		
206 MUX	Driving school mode		✓	✓	✓	✓		
206 MUX	Rain/brightness sensor		✓	✓	✓	✓		
206 MUX	Power steering		✓	✓	✓	✓		
206 MUX	BSI		✓	✓	✓	✓		S0033
206 +	Engine	ME745	✓	✓	✓	✓	✓	S0034
206 +	Engine	ME749	✓	✓	✓	✓	✓	S0034
206 +	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034

206 +	Engine	J34P	✓	✓	✓	✓	✓	S0034
206 +	Engine	V343	✓	✓	✓	✓	✓	
206 +	Engine	DCN2	✓	✓	✓	✓		
206 +	Engine	EDC15C2	✓	✓	✓	✓	✓	
206 +	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206 +	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
206 +	Gearbox ECU	AL4 AT8 automatic gearbox	✓	✓	✓	✓	✓	
206 +	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
206 +	ABS or ESP ECU	ESPMK60 O	✓	✓	✓	✓	✓	S0035,S0039
206 +	Airbag ECU		✓	✓	✓	✓		
206 +	Air Conditioning		✓	✓	✓	✓		
206 +	Instrument panel		✓	✓	✓	✓	✓	
206 +	Electric Power Steering		✓	✓	✓	✓		
206 +	Display/Telematics	AMF	✓	✓	✓	✓	✓	

206 +	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206 +	Service module		✓	✓	✓	✓	✓	
206 +	BSI		✓	✓	✓	✓		S0033
207 VAN	Engine	ME745	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	ME749	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	V343	✓	✓	✓	✓	✓	
207 VAN	Engine	DCN2	✓	✓	✓	✓		
207 VAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 VAN	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 VAN	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
207 VAN	Gearbox ECU	AL4 AT8 automatic gearbox	✓	✓	✓	✓	✓	
207 VAN	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039

207 VAN	ABS or ESP ECU	ESPMK60 O	✓	✓	✓	✓	✓	S0035,S0039
207 VAN	Airbag ECU		✓	✓	✓	✓		
207 VAN	Air Conditioning		✓	✓	✓	✓		
207 VAN	Instrument panel		✓	✓	✓	✓	✓	
207 VAN	Electric Power Steering		✓	✓	✓	✓		
207 VAN	Display/Telematics	AMF	✓	✓	✓	✓	✓	
207 VAN	Display/Telematics	RT3	✓	✓	✓	✓	✓	
207 VAN	Service module		✓	✓	✓	✓	✓	
207 VAN	BSI		✓	✓	✓	✓		S0033
207 CAN	Engine	ME745	✓	✓	✓	✓	✓	
207 CAN	Engine	MM6LPC	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034



207 CAN	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	V341	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	DCN2	✓	✓	✓	✓		
207 CAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 CAN	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 CAN	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
207 CAN	Gearbox ECU	Controlled manual gearbox MAP	✓	✓	✓	✓	✓	
207 CAN	Gearbox ECU	AL4 automatic gearbox	✓	✓	✓	✓	✓	
207 CAN	ABS/ESP	MK70.1	✓	✓	✓	✓	✓	S0039
207 CAN	ABS/ESP	ESP MK60 O	✓	✓	✓	✓	✓	S0039,S0035
207 CAN	Airbag ECU	SAC AUTOLIV	✓	✓	✓	✓		
207 CAN	Instrument Panel		✓	✓	✓	✓	✓	
207 CAN	Multiplexed Additive Adding Pump(POMPE MUX MGI)		✓	✓	✓	✓		

207 CAN	Air Conditioning		✓	✓	✓	✓	✓	
207 CAN	ALARM		✓	✓	✓	✓	✓	
207 CAN	Under inflation detection		✓	✓	✓	✓		
207 CAN	Power steering		✓	✓	✓	✓		
207 CAN	Battery charge status unit		✓	✓	✓	✓		S003A
207 CAN	Hands Free Kit	Hands Free Kit(BOITIER NOMADE)	✓	✓	✓	✓	✓	
207 CAN	Hands Free Kit	Hands Free Kit(KML)	✓	✓	✓	✓	✓	
207 CAN	Driving School Mode		✓	✓	✓	✓		
207 CAN	Headlamp Height Corrector		✓	✓	✓	✓	✓	
207 CAN	Multifunction Display		✓	✓	✓	✓	✓	
207 CAN	RADIO		✓	✓	✓	✓	✓	
207 CAN	Switch module at the steering wheel		✓	✓	✓	✓	✓	
207 CAN	Folding roof		✓	✓	✓	✓	✓	
207 CAN	High frequency receiver		✓	✓	✓	✓		

207 CAN	Rain/sunlight sensor		✓	✓	✓	✓		
207 CAN	Telematics	Telematic case	✓	✓	✓	✓	✓	
207 CAN	Telematics	Radio alarm	✓	✓	✓	✓		
207 CAN	Warning light showing seat belt not fastened		✓	✓	✓	✓		
207 i	Engine	ME745	✓	✓	✓	✓	✓	S0034
207 i	Engine	ME749	✓	✓	✓	✓	✓	S0034
207 i	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
207 i	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 i	Engine	V343	✓	✓	✓	✓	✓	
207 i	Engine	DCN2	✓	✓	✓	✓		
207 i	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 i	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 i	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
207 i	Gearbox ECU	AL4 AT8 automatic gearbox	✓	✓	✓	✓	✓	

207 i	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207 i	ABS or ESP ECU	ESPMK60 O	✓	✓	✓	✓	✓	S0035,S0039
207 i	Airbag ECU		✓	✓	✓	✓		
207 i	Air Conditioning		✓	✓	✓	✓		
207 i	Instrument panel		✓	✓	✓	✓	✓	
207 i	Electric Power Steering		✓	✓	✓	✓		
207 i	Display/Telematics	AMF	✓	✓	✓	✓	✓	
207 i	Display/Telematics	RT3	✓	✓	✓	✓	✓	
207 i	Service module		✓	✓	✓	✓	✓	
207 +	Engine	ME745	✓	✓	✓	✓	✓	
207 +	Engine	MM6LPC	✓	✓	✓	✓	✓	S0034
207 +	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 +	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 +	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034

207 +	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207 +	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207 +	Engine	V341	✓	✓	✓	✓	✓	S0034
207 +	Engine	DCN2	✓	✓	✓	✓		
207 +	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 +	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 +	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
207 +	Gearbox ECU	Controlled manual gearbox MAP	✓	✓	✓	✓	✓	
207 +	Gearbox ECU	AL4 automatic gearbox	✓	✓	✓	✓	✓	
207 +	ABS/ESP	MK70.1	✓	✓	✓	✓	✓	S0039
207 +	ABS/ESP	ESP MK60 O	✓	✓	✓	✓	✓	S0039,S0035
207 +	Airbag ECU	SAC AUTOLIV	✓	✓	✓	✓		
207 +	Airbag ECU	SAC GONFLABLE	✓	✓	✓	✓	✓	
207 +	Instrument Panel		✓	✓	✓	✓	✓	

207 +	Multiplexed Additive Adding Pump(POMPE MUX MGI)		✓	✓	✓	✓		
207 +	Air Conditioning		✓	✓	✓	✓	✓	
207 +	ALARM		✓	✓	✓	✓	✓	
207 +	Under inflation detection		✓	✓	✓	✓		
207 +	Power steering		✓	✓	✓	✓		
207 +	Battery charge status unit		✓	✓	✓	✓		S003A
207 +	Hands Free Kit	Hands Free Kit(BOITIER NOMADE)	✓	✓	✓	✓	✓	
207 +	Hands Free Kit	Hands Free Kit(KML)	✓	✓	✓	✓	✓	
207 +	Driving School Mode		✓	✓	✓	✓		
207 +	Headlamp Height Corrector		✓	✓	✓	✓	✓	
207 +	Multifunction Display		✓	✓	✓	✓	✓	
207 +	RADIO		✓	✓	✓	✓	✓	
207 +	Switch module at the steering wheel		✓	✓	✓	✓	✓	
207 +	Folding roof		✓	✓	✓	✓	✓	

207 +	High frequency receiver		✓	✓	✓	✓		
207 +	Rain/sunlight sensor		✓	✓	✓	✓		
207 +	Telematics	Telematic case	✓	✓	✓	✓	✓	
207 +	Telematics	Radio alarm	✓	✓	✓	✓		
207 +	Warning light showing seat belt not fastened		✓	✓	✓	✓		
301	Engine	V46	✓	✓	✓	✓	✓	
301	Engine	V46 21	✓	✓	✓	✓	✓	
301	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
301	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
301	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
301	Gearbox ECU	MAPS_UDS	✓	✓	✓	✓		
301	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
301	ABS	ABS MK100	✓	✓	✓	✓	✓	S0039
301	ABS	ESPMK100	✓	✓	✓	✓	✓	S0039

301	Airbag		✓	✓	✓	✓		
301	Instrument panel		✓	✓	✓	✓	✓	
301	BSI		✓	✓	✓	✓		S0033
301	Electric power steering		✓	✓	✓	✓		
301	Multiplexed Additive Adding Pump		✓	✓	✓	✓		
301	Parking aid		✓	✓	✓	✓		
301	Multi function display	EMF A	✓	✓	✓	✓		
301	Multi function display	EMF C	✓	✓	✓	✓		
301	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
301	RADIO	RD45	✓	✓	✓	✓	✓	
301	Steering Wheel Switching Module		✓	✓	✓	✓		
301	Trailer Relay Unit		✓	✓	✓	✓		
307 VAN	Engine	EDC16C3	✓	✓	✓	✓	✓	S0037,S0036
307 VAN	Engine	HDI_SID803	✓	✓	✓	✓	✓	S0037



307 VAN	Engine	ME745	✓	✓	✓	✓	✓	S0034
307 VAN	Engine	MM6LP	✓	✓	✓	✓		
307 VAN	Engine	ME744	✓	✓	✓	✓	✓	S0034
307 VAN	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ABS BOSCH8	✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ESP BOSCH8	✓	✓	✓	✓	✓	S0035,S0039
307 VAN	ABS/ESP	ESP BOSCH57	✓	✓	✓	✓	✓	S0035,S0039
307 VAN	ABS/ESP	ABS BOSCH53	✓	✓	✓	✓		
307 VAN	Air bags		✓	✓	✓	✓		
307 VAN	Instrument panel		✓	✓	✓	✓	✓	
307 VAN	Diesel fuel additive control unit		✓	✓	✓	✓		
307 VAN	Air Conditioning		✓	✓	✓	✓		
307 VAN	Alarm		✓	✓	✓	✓		
307 VAN	Power Steering		✓	✓	✓	✓		

307 VAN	Switch module at the steering wheel		✓	✓	✓	✓		
307 VAN	Multi function display		✓	✓	✓	✓	✓	
307 VAN	Parking aid		✓	✓	✓	✓		
307 VAN	Radio		✓	✓	✓	✓	✓	
307 VAN	CD Player		✓	✓	✓	✓		
307 VAN	Driving school mode		✓	✓	✓	✓		
307 VAN	Roll over ECU		✓	✓	✓	✓		
307 VAN	Sun roof	TO WEBASTO	✓	✓	✓	✓		
307 VAN	Sun roof	TOUV TEXTON	✓	✓	✓	✓		
307 CAN	Engine	ME745	✓	✓	✓	✓	✓	S0034,S0040,S0041,S0042
307 CAN	Engine	KFU MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFK MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFN MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFJ MM6LPB	✓	✓	✓	✓	✓	S0034

307 CAN	Engine	KFU MM6LPC	√	√	√	√	√	S0034
307 CAN	Engine	ME749	√	√	√	√	√	S0034
307 CAN	Engine	ME749 BioFlex	√	√	√	√	√	
307 CAN	Engine	ME749 EC5	√	√	√	√	√	
307 CAN	Engine	MM6KP BioFlex	√	√	√	√	√	S0034
307 CAN	Engine	MM6KP Non BioFlex	√	√	√	√	√	
307 CAN	Engine	DCM3.4	√	√	√	√	√	S0037,S0036
307 CAN	Engine	EDC15C2	√	√	√	√	√	
307 CAN	Engine	9HV BOSCH EDC16C3	√	√	√	√	√	S0036
307 CAN	Engine	9HX BOSCH EDC16C3	√	√	√	√	√	
307 CAN	Engine	9HY BOSCH EDC16C3	√	√	√	√	√	
307 CAN	Engine	9HZ BOSCH EDC16C3	√	√	√	√	√	
307 CAN	Engine	HDI SID803	√	√	√	√	√	
307 CAN	Engine	HDI SID803A	√	√	√	√	√	

307 CAN	Gearbox ECU	BVA AL4 AT8	✓	✓	✓	✓	✓	
307 CAN	Gearbox ECU	AM6 automatic gearbox	✓	✓	✓	✓	✓	
307 CAN	ABS/ESP	ABS8 BOSCH	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ABS8.1	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ESP BOCSH8	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ESP8.1	✓	✓	✓	✓	✓	S0039,S0035
307 CAN	Air bag	SAC AUTOLIV	✓	✓	✓	✓		
307 CAN	Air bag	SAC GONFLABLE	✓	✓	✓	✓		
307 CAN	Instrument panel		✓	✓	✓	✓	✓	
307 CAN	BSI		✓	✓	✓	✓		S0033
307 CAN	Multiplexed additive adding pump ECU		✓	✓	✓	✓	✓	
307 CAN	Parking aid		✓	✓	✓	✓	✓	
307 CAN	Air Conditioning		✓	✓	✓	✓	✓	
307 CAN	Under inflation detection		✓	✓	✓	✓		

307 CAN	Power Steering		√	√	√	√	√	
307 CAN	Multi function display		√	√	√	√	√	
307 CAN	Radio		√	√	√	√	√	
307 CAN	CD Player		√	√	√	√		
307 CAN	Switch module at the steering wheel		√	√	√	√	√	
307 CAN	Hand Free Kit		√	√	√	√	√	
307 CAN	Telematics		√	√	√	√	√	
307 CAN	Alarm		√	√	√	√	√	
307 CAN	Driver's door module		√	√	√	√	√	
307 CAN	Passenger door module		√	√	√	√	√	
307 CAN	Retractable roof		√	√	√	√	√	
307 CAN	Sun roof		√	√	√	√		
307 CAN	Rain/brightness sensor		√	√	√	√		
308	Engine	ME745	√	√	√	√	√	

308	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
308	Engine	ME749	✓	✓	✓	✓	✓	
308	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
308	Engine	MM6LPB	✓	✓	✓	✓	✓	
308	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
308	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034
308	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	Engine	MED17 4 2	✓	✓	✓	✓	✓	
308	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
308	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034

308	Engine	EDC16C3	✓	✓	✓	✓	✓	
308	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
308	Engine	DCM35	✓	✓	✓	✓	✓	S0037,S0036
308	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0037,S0036
308	Engine	SID807	✓	✓	✓	✓	✓	S0037
308	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
308	Engine	EDC17C10	✓	✓	✓	✓	✓	S0037,S0036
308	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
308	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
308	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
308	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
308	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
308	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0039,S0035

308	Air bag		✓	✓	✓	✓		
308	Instrument Panel		✓	✓	✓	✓	✓	
308	BSI		✓	✓	✓	✓		S0033
308	AC CLIM		✓	✓	✓	✓	✓	
308	Alarm	ALARME	✓	✓	✓	✓	✓	
308	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
308	Power steering		✓	✓	✓	✓	✓	
308	Hands Free Kit	Hands Free Kit(BOITIER NOMADE)	✓	✓	✓	✓	✓	
308	Hands Free Kit	Hands Free Kit(KML)	✓	✓	✓	✓	✓	
308	Under inflation detection		✓	✓	✓	✓		
308	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308	Driver's Door Module		✓	✓	✓	✓	✓	
308	Driving School Mode		✓	✓	✓	✓		
308	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	



308	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
308	Headlamp Height Corrector		✓	✓	✓	✓	✓	
308	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
308	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
308	Parking Aid(AAS)		✓	✓	✓	✓		
308	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
308	Battery change status unit	BECB	✓	✓	✓	✓		S003A
308	Battery change status unit	BECB GEN2	✓	✓	✓	✓		S003A
308	Battery change status unit	BLVV(KWP)	✓	✓	✓	✓		
308	Battery change status unit	BTA	✓	✓	✓	✓		
308	Battery change status unit	MD SERV	✓	✓	✓	✓		
308	CD player		✓	✓	✓	✓		
308	Engine relay unit		✓	✓	✓	✓	✓	
308	ESSUIV		✓	✓	✓	✓		

308	Hi fi amplifier		✓	✓	✓	✓		
308	Lane departure warning system		✓	✓	✓	✓	✓	
308	Control panel dot matrix display		✓	✓	✓	✓	✓	
308	Multi function display	EMF A	✓	✓	✓	✓	✓	
308	Multi function display	EMF C	✓	✓	✓	✓	✓	
308	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
308	RADIO	RD43	✓	✓	✓	✓		
308	RADIO	RD45	✓	✓	✓	✓	✓	
308	Rain Sensor		✓	✓	✓	✓		
308	SUN ROOF		✓	✓	✓	✓		
308	TOITESC		✓	✓	✓	✓		
308	Trailer relay unit		✓	✓	✓	✓	✓	
308 4 Portes	Engine	ME745	✓	✓	✓	✓	✓	
308 4 Portes	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034

308 4 Portes	Engine	ME749	✓	✓	✓	✓	✓	
308 4 Portes	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6LPB	✓	✓	✓	✓	✓	
308 4 Portes	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MED17 4 2	✓	✓	✓	✓	✓	
308 4 Portes	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	EDC16C3	✓	✓	✓	✓	✓	

308 4 Portes	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
308 4 Portes	Engine	DCM35	✓	✓	✓	✓	✓	S0037,S0036
308 4 Portes	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0037,S0036
308 4 Portes	Engine	SID807	✓	✓	✓	✓	✓	S0037
308 4 Portes	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
308 4 Portes	Engine	EDC17C10	✓	✓	✓	✓	✓	S0037,S0036
308 4 Portes	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037,S0036
308 4 Portes	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
308 4 Portes	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
308 4 Portes	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0039,S0035
308 4 Portes	Air bag		✓	✓	✓	✓		

308 4 Portes	Instrument Panel		✓	✓	✓	✓	✓	
308 4 Portes	BSI		✓	✓	✓	✓		S0033
308 4 Portes	AC CLIM		✓	✓	✓	✓	✓	
308 4 Portes	Alarm	ALARME	✓	✓	✓	✓	✓	
308 4 Portes	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
308 4 Portes	Power steering		✓	✓	✓	✓	✓	
308 4 Portes	Hands Free Kit	Hands Free Kit(BOITIER NOMADE)	✓	✓	✓	✓	✓	
308 4 Portes	Hands Free Kit	Hands Free Kit(KML)	✓	✓	✓	✓	✓	
308 4 Portes	Under inflation detection		✓	✓	✓	✓		
308 4 Portes	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308 4 Portes	Driver's Door Module		✓	✓	✓	✓	✓	
308 4 Portes	Driving School Mode		✓	✓	✓	✓		
308 4 Portes	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
308 4 Portes	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	

308 4 Portes	Headlamp Height Corrector		✓	✓	✓	✓	✓	
308 4 Portes	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
308 4 Portes	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
308 4 Portes	Parking Aid(AAS)		✓	✓	✓	✓		
308 4 Portes	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
308 4 Portes	Battery change status unit	BECB	✓	✓	✓	✓		S003A
308 4 Portes	Battery change status unit	BECB GEN2	✓	✓	✓	✓		S003A
308 4 Portes	Battery change status unit	BLVV(KWP)	✓	✓	✓	✓		
308 4 Portes	Battery change status unit	BTA	✓	✓	✓	✓		
308 4 Portes	Battery change status unit	MD SERV	✓	✓	✓	✓		
308 4 Portes	CD player		✓	✓	✓	✓		
308 4 Portes	Engine relay unit		✓	✓	✓	✓	✓	
308 4 Portes	ESSUIV		✓	✓	✓	✓		
308 4 Portes	Hi fi amplifier		✓	✓	✓	✓		

308 4 Portes	Lane departure warning system		✓	✓	✓	✓	✓	
308 4 Portes	Control panel dot matrix display		✓	✓	✓	✓	✓	
308 4 Portes	Multi function display	EMF A	✓	✓	✓	✓	✓	
308 4 Portes	Multi function display	EMF C	✓	✓	✓	✓	✓	
308 4 Portes	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
308 4 Portes	RADIO	RD43	✓	✓	✓	✓		
308 4 Portes	RADIO	RD45	✓	✓	✓	✓	✓	
308 4 Portes	Rain Sensor		✓	✓	✓	✓		
308 4 Portes	SUN ROOF		✓	✓	✓	✓		
308 4 Portes	TOITESC		✓	✓	✓	✓		
308 4 Portes	Trailer relay unit		✓	✓	✓	✓	✓	
3008	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
3008	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034

3008	Engine	MED17 4 EURO5	√	√	√	√	√	S0034
3008	Engine	MEV17 4 EURO4	√	√	√	√	√	S0034
3008	Engine	MEV17 4 EURO5	√	√	√	√	√	S0034
3008	Engine	MM6KP	√	√	√	√	√	S0034
3008	Engine	MM6KP bio	√	√	√	√	√	S0034
3008	Engine	DCM35	√	√	√	√	√	S0036,S0037
3008	Engine	DCM35 BR2	√	√	√	√	√	S0037,S0036
3008	Engine	DCM35 HY	√	√	√	√	√	S0037,S0036
3008	Engine	EDC16C3	√	√	√	√	√	S0037,S0036
3008	Engine	SID807	√	√	√	√	√	S0037
3008	Engine	SID807 BR2	√	√	√	√	√	S0037
3008	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
3008	Gearbox ECU	CFC300P	√	√	√	√	√	
3008	Gearbox ECU	CFC300P HY	√	√	√	√	√	



3008	ABS or ESP ECU	ESP81	√	√	√	√	√	S0039,S0035,S0038
3008	Air bag		√	√	√	√		
3008	BSI		√	√	√	√		S0033
3008	Instrument Panel		√	√	√	√	√	
3008	Air Conditioning		√	√	√	√	√	
3008	Under inflation detection		√	√	√	√		
3008	Power steering		√	√	√	√	√	
3008	Electric parking brake		√	√	√	√	√	S0038
3008	ALARM		√	√	√	√	√	
3008	Assistance In Complying With The Inter Vehicle Time Artiv		√	√	√	√		
3008	Battery charge status unit		√	√	√	√		S003A
3008	Hands Free Kit		√	√	√	√	√	
3008	Windscreen Wiper Control Unit		√	√	√	√		
3008	Driver's Door Module		√	√	√	√	√	

3008	Headlamp Height Corrector		✓	✓	✓	✓	✓	
3008	Lane Departure Warning System		✓	✓	✓	✓		
3008	Multifunction Display	Multifunction Display A	✓	✓	✓	✓	✓	
3008	Multifunction Display	Multifunction Display C	✓	✓	✓	✓	✓	
3008	Multiplexed Additive Adding Pump	POMPE MUX MGI	✓	✓	✓	✓	✓	
3008	Multiplexed Additive Adding Pump	POMPE MUX TI	✓	✓	✓	✓	✓	
3008	Parking Aid(AAS)		✓	✓	✓	✓	✓	
3008	RADIO		✓	✓	✓	✓	✓	
3008	Service Module	Service Module(BTA)	✓	✓	✓	✓	✓	
3008	Service Module	Service Module(MD SERV)	✓	✓	✓	✓	✓	
3008	Telematics	Telematics(RADIONAV NG4)	✓	✓	✓	✓	✓	
3008	Telematics	Telematics(RADIONAV RNEG)	✓	✓	✓	✓		
3008	Anti slip mode selector		✓	✓	✓	✓	✓	
3008	Audio amplifier		✓	✓	✓	✓	✓	

3008	CD player		✓	✓	✓	✓		
3008	Control panel dot matrix display		✓	✓	✓	✓	✓	
3008	High Head Vision		✓	✓	✓	✓		
3008	Network isolation unit		✓	✓	✓	✓		
3008	Rain sensor		✓	✓	✓	✓		
3008	Switch module at the steering wheel		✓	✓	✓	✓	✓	
3008	Not Fastened warning lingt(TNB)		✓	✓	✓	✓		
3008 Hybrid4	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
3008 Hybrid4	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MM6KP	✓	✓	✓	✓	✓	S0034

3008 Hybrid4	Engine	MM6KP bio	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	DCM35	✓	✓	✓	✓	✓	S0036,S0037
3008 Hybrid4	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0037,S0036
3008 Hybrid4	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0037,S0036
3008 Hybrid4	Engine	EDC16C3	✓	✓	✓	✓	✓	S0037,S0036
3008 Hybrid4	Engine	SID807	✓	✓	✓	✓	✓	S0037
3008 Hybrid4	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
3008 Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008 Hybrid4	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
3008 Hybrid4	Gearbox ECU	CFC300P HY	✓	✓	✓	✓	✓	
3008 Hybrid4	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0039,S0035,S0038
3008 Hybrid4	Air bag		✓	✓	✓	✓		
3008 Hybrid4	BSI		✓	✓	✓	✓		S0033
3008 Hybrid4	Instrument Panel		✓	✓	✓	✓	✓	

3008 Hybrid4	Air Conditioning		✓	✓	✓	✓	✓	
3008 Hybrid4	Under inflation detection		✓	✓	✓	✓		
3008 Hybrid4	Power steering		✓	✓	✓	✓	✓	
3008 Hybrid4	Electric parking brake		✓	✓	✓	✓	✓	S0038
3008 Hybrid4	ALARM		✓	✓	✓	✓	✓	
3008 Hybrid4	Assistance In Complying With The Inter Vehicle Time Artiv		✓	✓	✓	✓		
3008 Hybrid4	Battery charge status unit		✓	✓	✓	✓		S003A
3008 Hybrid4	Hands Free Kit		✓	✓	✓	✓	✓	
3008 Hybrid4	Windscreen Wiper Control Unit		✓	✓	✓	✓		
3008 Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
3008 Hybrid4	Headlamp Height Corrector		✓	✓	✓	✓	✓	
3008 Hybrid4	Lane Departure Warning System		✓	✓	✓	✓		
3008 Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓	✓	
3008 Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓	✓	

3008 Hybrid4	Multiplexed Additive Adding Pump	POMPE MUX MGI	✓	✓	✓	✓	✓	
3008 Hybrid4	Multiplexed Additive Adding Pump	POMPE MUX TI	✓	✓	✓	✓	✓	
3008 Hybrid4	Parking Aid(AAS)		✓	✓	✓	✓	✓	
3008 Hybrid4	RADIO		✓	✓	✓	✓	✓	
3008 Hybrid4	Service Module	Service Module(BTA)	✓	✓	✓	✓	✓	
3008 Hybrid4	Service Module	Service Module(MD SERV)	✓	✓	✓	✓	✓	
3008 Hybrid4	Telematics	Telematics(RADIONAV NG4)	✓	✓	✓	✓	✓	
3008 Hybrid4	Telematics	Telematics(RADIONAV RNEG)	✓	✓	✓	✓		
3008 Hybrid4	Anti slip mode selector		✓	✓	✓	✓	✓	
3008 Hybrid4	Audio amplifier		✓	✓	✓	✓	✓	
3008 Hybrid4	CD player		✓	✓	✓	✓		
3008 Hybrid4	Control panel dot matrix display		✓	✓	✓	✓	✓	
3008 Hybrid4	High Head Vision		✓	✓	✓	✓		
3008 Hybrid4	Network isolation unit		✓	✓	✓	✓		

3008 Hybrid4	Rain sensor		√	√	√	√		
3008 Hybrid4	Switch module at the steering wheel		√	√	√	√	√	
3008 Hybrid4	Not Fastened warning lingt(TNB)		√	√	√	√		
3008 China	Engine	MM6KP	√	√	√	√	√	S0034
3008 China	Engine	MED17 4 2	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 2	√	√	√	√	√	
3008 China	Engine	MED17 4 EURO4	√	√	√	√	√	S0034
3008 China	Engine	MED17 4 EURO5	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 EURO4	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 EURO5	√	√	√	√	√	S0034
3008 China	Engine	MM6KP	√	√	√	√	√	S0034
3008 China	Engine	MM6KP bio	√	√	√	√	√	S0034
3008 China	Engine	DCM35	√	√	√	√	√	S0036,S0037
3008 China	Engine	DCM35 BR2	√	√	√	√	√	S0037,S0036

3008 China	Engine	DCM35 HY	√	√	√	√	√	S0037,S0036
3008 China	Engine	EDC16C3	√	√	√	√	√	S0037,S0036
3008 China	Engine	SID807	√	√	√	√	√	S0037
3008 China	Engine	SID807 BR2	√	√	√	√	√	S0037
3008 China	Engine	MED17_4_4	√	√	√	√		S0034
3008 China	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
3008 China	Gearbox ECU	CFC300P	√	√	√	√	√	
3008 China	Gearbox ECU	CFC300P HY	√	√	√	√	√	
3008 China	ABS or ESP ECU	ESP81	√	√	√	√	√	S0039,S0035,S0038
3008 China	Air bag		√	√	√	√		
3008 China	BSI		√	√	√	√		S0033
3008 China	Instrument Panel		√	√	√	√	√	
3008 China	Air Conditioning		√	√	√	√	√	
3008 China	Under inflation detection		√	√	√	√		



3008 China	Power steering		√	√	√	√	√	
3008 China	Electric parking brake		√	√	√	√	√	S0038
3008 China	ALARM		√	√	√	√	√	
3008 China	Assistance In Complying With The Inter Vehicle Time Artiv		√	√	√	√		
3008 China	Battery charge status unit		√	√	√	√		S003A
3008 China	Hands Free Kit		√	√	√	√	√	
3008 China	Windscreen Wiper Control Unit		√	√	√	√		
3008 China	Driver's Door Module		√	√	√	√	√	
3008 China	Headlamp Height Corrector		√	√	√	√	√	
3008 China	Lane Departure Warning System		√	√	√	√		
3008 China	Multifunction Display	Multifunction Display A	√	√	√	√	√	
3008 China	Multifunction Display	Multifunction Display C	√	√	√	√	√	
3008 China	Multiplexed Additive Adding Pump	POMPE MUX MGI	√	√	√	√	√	
3008 China	Multiplexed Additive Adding Pump	POMPE MUX TI	√	√	√	√	√	

3008 China	Parking Aid(AAS)		√	√	√	√	√	
3008 China	RADIO		√	√	√	√	√	
3008 China	Service Module	Service Module(BTA)	√	√	√	√	√	
3008 China	Service Module	Service Module(MD SERV)	√	√	√	√	√	
3008 China	Telematics	Telematics(RADIONAV NG4)	√	√	√	√	√	
3008 China	Telematics	Telematics(RADIONAV RNEG)	√	√	√	√		
3008 China	Anti slip mode selector		√	√	√	√	√	
3008 China	Audio amplifier		√	√	√	√	√	
3008 China	CD player		√	√	√	√		
3008 China	Control panel dot matrix display		√	√	√	√	√	
3008 China	High Head Vision		√	√	√	√		
3008 China	Network isolation unit		√	√	√	√		
3008 China	Rain sensor		√	√	√	√		
3008 China	Switch module at the steering wheel		√	√	√	√	√	

3008 China	Not Fastened warning lingt(TNB)		√	√	√	√		
5008	Engine	MED17 4 2	√	√	√	√	√	S0034
5008	Engine	MEV17 4 2	√	√	√	√	√	
5008	Engine	MED17 4 EURO4	√	√	√	√	√	S0034
5008	Engine	MED17 4 EURO5	√	√	√	√	√	S0034
5008	Engine	MEV17 4 EURO4	√	√	√	√	√	S0034
5008	Engine	MEV17 4 EURO5	√	√	√	√	√	S0034
5008	Engine	MM6KP	√	√	√	√	√	S0034
5008	Engine	MM6KP bio	√	√	√	√	√	S0034
5008	Engine	DCM35	√	√	√	√	√	S0036,S0037
5008	Engine	DCM35 BR2	√	√	√	√	√	S0037,S0036
5008	Engine	DCM35 HY	√	√	√	√	√	S0037,S0036
5008	Engine	EDC16C3	√	√	√	√	√	S0037,S0036
5008	Engine	SID807	√	√	√	√	√	S0037

5008	Engine	SID807 BR2	√	√	√	√	√	S0037
5008	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
5008	Gearbox ECU	CFC300P	√	√	√	√	√	
5008	Gearbox ECU	CFC300P HY	√	√	√	√	√	
5008	ABS or ESP ECU	ESP81	√	√	√	√	√	S0039,S0035,S0038
5008	Air bag		√	√	√	√		
5008	BSI		√	√	√	√		S0033
5008	Instrument Panel		√	√	√	√	√	
5008	Air Conditioning		√	√	√	√	√	
5008	Under inflation detection		√	√	√	√		
5008	Power steering		√	√	√	√	√	
5008	Electric parking brake		√	√	√	√	√	S0038
5008	ALARM		√	√	√	√	√	
5008	Assistance In Complying With The Inter Vehicle Time Artiv		√	√	√	√		

5008	Battery charge status unit		√	√	√	√		S003A
5008	Hands Free Kit		√	√	√	√	√	
5008	Windscreen Wiper Control Unit		√	√	√	√		
5008	Driver's Door Module		√	√	√	√	√	
5008	Headlamp Height Corrector		√	√	√	√	√	
5008	Lane Departure Warning System		√	√	√	√		
5008	Multifunction Display	Multifunction Display A	√	√	√	√	√	
5008	Multifunction Display	Multifunction Display C	√	√	√	√	√	
5008	Multiplexed Additive Adding Pump	POMPE MUX MGI	√	√	√	√	√	
5008	Multiplexed Additive Adding Pump	POMPE MUX TI	√	√	√	√	√	
5008	Parking Aid(AAS)		√	√	√	√	√	
5008	RADIO		√	√	√	√	√	
5008	Service Module	Service Module(BTA)	√	√	√	√	√	
5008	Service Module	Service Module(MD SERV)	√	√	√	√	√	

5008	Telematics	Telematics(RADIONAV NG4)	√	√	√	√	√	
5008	Telematics	Telematics(RADIONAV RNEG)	√	√	√	√		
5008	Anti slip mode selector		√	√	√	√	√	
5008	Audio amplifier		√	√	√	√	√	
5008	CD player		√	√	√	√		
5008	Control panel dot matrix display		√	√	√	√	√	
5008	High Head Vision		√	√	√	√		
5008	Network isolation unit		√	√	√	√		
5008	Rain sensor		√	√	√	√		
5008	Switch module at the steering wheel		√	√	√	√	√	
5008	Not Fastened warning lingt(TNB)		√	√	√	√		
408(T73)	Engine	ME745	√	√	√	√	√	
408(T73)	Engine	ME745 EC5	√	√	√	√	√	S0034
408(T73)	Engine	ME749	√	√	√	√	√	

408(T73)	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MM6LPB	✓	✓	✓	✓	✓	
408(T73)	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MED17 4 2	✓	✓	✓	✓	✓	
408(T73)	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
408(T73)	Engine	EDC16C3	✓	✓	✓	✓	✓	
408(T73)	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036

408(T73)	Engine	DCM35	√	√	√	√	√	S0037,S0036
408(T73)	Engine	DCM35 BR2	√	√	√	√	√	S0037,S0036
408(T73)	Engine	SID807	√	√	√	√	√	S0037
408(T73)	Engine	SID807 BR2	√	√	√	√	√	S0037
408(T73)	Engine	EDC17C10	√	√	√	√	√	S0037,S0036
408(T73)	Engine	EDC17C10 BR2	√	√	√	√	√	S0037,S0036
408(T73)	Gearbox ECU	BVA AT8	√	√	√	√	√	
408(T73)	Gearbox ECU	BVA AM6	√	√	√	√	√	
408(T73)	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
408(T73)	Gearbox ECU	CFC300P	√	√	√	√	√	
408(T73)	ABS or ESP ECU	ABS81	√	√	√	√	√	S0039
408(T73)	ABS or ESP ECU	ESP81	√	√	√	√	√	S0039,S0035
408(T73)	Air bag		√	√	√	√		
408(T73)	Instrument Panel		√	√	√	√	√	



408(T73)	BSI		✓	✓	✓	✓		S0033
408(T73)	AC CLIM		✓	✓	✓	✓	✓	
408(T73)	Alarm	ALARME	✓	✓	✓	✓	✓	
408(T73)	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
408(T73)	Power steering		✓	✓	✓	✓	✓	
408(T73)	Hands Free Kit	Hands Free Kit(BOITIER NOMADE)	✓	✓	✓	✓	✓	
408(T73)	Hands Free Kit	Hands Free Kit(KML)	✓	✓	✓	✓	✓	
408(T73)	Under inflation detection		✓	✓	✓	✓		
408(T73)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
408(T73)	Driver's Door Module		✓	✓	✓	✓	✓	
408(T73)	Driving School Mode		✓	✓	✓	✓		
408(T73)	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
408(T73)	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
408(T73)	Headlamp Height Corrector		✓	✓	✓	✓	✓	

408(T73)	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	√	√	√	√	√	
408(T73)	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	√	√	√	√		
408(T73)	Parking Aid(AAS)		√	√	√	√		
408(T73)	Pedestrian Impact Detection Unit		√	√	√	√		
408(T73)	Battery change status unit	BECB	√	√	√	√		S003A
408(T73)	Battery change status unit	BECB GEN2	√	√	√	√		S003A
408(T73)	Battery change status unit	BLVV(KWP)	√	√	√	√		
408(T73)	Battery change status unit	BTA	√	√	√	√		
408(T73)	Battery change status unit	MD SERV	√	√	√	√		
408(T73)	CD player		√	√	√	√		
408(T73)	Engine relay unit		√	√	√	√	√	
408(T73)	ESSUIV		√	√	√	√		
408(T73)	Hi fi amplifier		√	√	√	√		
408(T73)	Lane departure warning system		√	√	√	√	√	

408(T73)	Control panel dot matrix display		✓	✓	✓	✓	✓	
408(T73)	Multi function display	EMF A	✓	✓	✓	✓	✓	
408(T73)	Multi function display	EMF C	✓	✓	✓	✓	✓	
408(T73)	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
408(T73)	RADIO	RD43	✓	✓	✓	✓		
408(T73)	RADIO	RD45	✓	✓	✓	✓	✓	
408(T73)	Rain Sensor		✓	✓	✓	✓		
408(T73)	SUN ROOF		✓	✓	✓	✓		
408(T73)	TOITESC		✓	✓	✓	✓		
408(T73)	Trailer relay unit		✓	✓	✓	✓	✓	
508	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034

508	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
508	Engine	DCM35	✓	✓	✓	✓	✓	
508	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0037,S0036
508	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508	Engine	MED17_4_4	✓	✓	✓	✓		S0034
508	Engine	MED17_4_4EP8	✓	✓	✓	✓		
508	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		
508	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
508	ABS	ABS81	✓	✓	✓	✓	✓	S0039,S0035
508	ABS	ESP81	✓	✓	✓	✓	✓	S0039,S0035,S0038

508	BSI		✓	✓	✓	✓		S0033
508	Airbag		✓	✓	✓	✓		
508	Instrument panel		✓	✓	✓	✓	✓	
508	Air Conditioning		✓	✓	✓	✓	✓	
508	Power steering electric pump unit		✓	✓	✓	✓	✓	
508	Under inflation detection		✓	✓	✓	✓		
508	Battery charge status unit		✓	✓	✓	✓		
508	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508	Engine relay unit		✓	✓	✓	✓		
508	Trailer relay unit		✓	✓	✓	✓		
508	Parking aid		✓	✓	✓	✓		
508	Anti theft alarm		✓	✓	✓	✓	✓	
508	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		

508	Telematics unit		✓	✓	✓	✓	✓	
508	Active damper electronic unit		✓	✓	✓	✓		
508	Multiplexed control panel		✓	✓	✓	✓		
508	Matrix screen integral to the instrument panel		✓	✓	✓	✓		
508	Radio		✓	✓	✓	✓	✓	
508	Radio amplifier		✓	✓	✓	✓		
508	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508	Driver's Door Module		✓	✓	✓	✓	✓	
508	Motorised Boot ECU		✓	✓	✓	✓		
508	High Head Vision		✓	✓	✓	✓		
508	Electric secondary brake		✓	✓	✓	✓		S0038
508	Main beams assistant ECU		✓	✓	✓	✓		
508	Electric steering lock		✓	✓	✓	✓		
508 Hybrid4	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034

508 Hybrid4	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 Hybrid4	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508 Hybrid4	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508 Hybrid4	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508 Hybrid4	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
508 Hybrid4	Engine	DCM35	✓	✓	✓	✓	✓	
508 Hybrid4	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0037,S0036
508 Hybrid4	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 Hybrid4	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 Hybrid4	Engine	MED17_4_4	✓	✓	✓	✓		S0034
508 Hybrid4	Engine	MED17_4_4EP8	✓	✓	✓	✓		
508 Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 Hybrid4	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508 Hybrid4	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		

508 Hybrid4	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
508 Hybrid4	ABS	ABS81	✓	✓	✓	✓	✓	S0039,S0035
508 Hybrid4	ABS	ESP81	✓	✓	✓	✓	✓	S0039,S0035,S0038
508 Hybrid4	BSI		✓	✓	✓	✓		S0033
508 Hybrid4	Airbag		✓	✓	✓	✓		
508 Hybrid4	Instrument panel		✓	✓	✓	✓	✓	
508 Hybrid4	Air Conditioning		✓	✓	✓	✓	✓	
508 Hybrid4	Power steering electric pump unit		✓	✓	✓	✓	✓	
508 Hybrid4	Under inflation detection		✓	✓	✓	✓		
508 Hybrid4	Battery charge status unit		✓	✓	✓	✓		
508 Hybrid4	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508 Hybrid4	Engine relay unit		✓	✓	✓	✓		
508 Hybrid4	Trailer relay unit		✓	✓	✓	✓		
508 Hybrid4	Parking aid		✓	✓	✓	✓		



508 Hybrid4	Anti theft alarm		✓	✓	✓	✓	✓	
508 Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 Hybrid4	Telematics unit		✓	✓	✓	✓	✓	
508 Hybrid4	Active damper electronic unit		✓	✓	✓	✓		
508 Hybrid4	Multiplexed control panel		✓	✓	✓	✓		
508 Hybrid4	Matrix screen integral to the instrument panel		✓	✓	✓	✓		
508 Hybrid4	Radio		✓	✓	✓	✓	✓	
508 Hybrid4	Radio amplifier		✓	✓	✓	✓		
508 Hybrid4	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
508 Hybrid4	Motorised Boot ECU		✓	✓	✓	✓		
508 Hybrid4	High Head Vision		✓	✓	✓	✓		
508 Hybrid4	Electric secondary brake		✓	✓	✓	✓		S0038

508 Hybrid4	Main beams assistant ECU		✓	✓	✓	✓		
508 Hybrid4	Electric steering lock		✓	✓	✓	✓		
508 RXH	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
508 RXH	Engine	DCM35	✓	✓	✓	✓	✓	
508 RXH	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0037,S0036
508 RXH	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 RXH	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH	Engine	MED17_4_4	✓	✓	✓	✓		S0034
508 RXH	Engine	MED17_4_4EP8	✓	✓	✓	✓		

508 RXH	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
508 RXH	Gearbox ECU	CFC300P	√	√	√	√	√	
508 RXH	Gearbox ECU	CFC300P HY	√	√	√	√		
508 RXH	Gearbox ECU	BVA_AM6_AT6_UDS	√	√	√	√		
508 RXH	ABS	ABS81	√	√	√	√	√	S0039,S0035
508 RXH	ABS	ESP81	√	√	√	√	√	S0039,S0035,S0038
508 RXH	BSI		√	√	√	√		S0033
508 RXH	Airbag		√	√	√	√		
508 RXH	Instrument panel		√	√	√	√	√	
508 RXH	Air Conditioning		√	√	√	√	√	
508 RXH	Power steering electric pump unit		√	√	√	√	√	
508 RXH	Under inflation detection		√	√	√	√		
508 RXH	Battery charge status unit		√	√	√	√		
508 RXH	Headlamp height adjuster/directional headlamp		√	√	√	√	√	

508 RXH	Engine relay unit		✓	✓	✓	✓		
508 RXH	Trailer relay unit		✓	✓	✓	✓		
508 RXH	Parking aid		✓	✓	✓	✓		
508 RXH	Anti theft alarm		✓	✓	✓	✓	✓	
508 RXH	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 RXH	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 RXH	Telematics unit		✓	✓	✓	✓	✓	
508 RXH	Active damper electronic unit		✓	✓	✓	✓		
508 RXH	Multiplexed control panel		✓	✓	✓	✓		
508 RXH	Matrix screen integral to the instrument panel		✓	✓	✓	✓		
508 RXH	Radio		✓	✓	✓	✓	✓	
508 RXH	Radio amplifier		✓	✓	✓	✓		
508 RXH	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 RXH	Driver's Door Module		✓	✓	✓	✓	✓	

508 RXH	Motorised Boot ECU		✓	✓	✓	✓		
508 RXH	High Head Vision		✓	✓	✓	✓		
508 RXH	Electric secondary brake		✓	✓	✓	✓		S0038
508 RXH	Main beams assistant ECU		✓	✓	✓	✓		
508 RXH	Electric steering lock		✓	✓	✓	✓		
508 RXH Hybrid4	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	DCM34	✓	✓	✓	✓	✓	S0037,S0036
508 RXH Hybrid4	Engine	DCM35	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0037,S0036
508 RXH Hybrid4	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037

508 RXH Hybrid4	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH Hybrid4	Engine	MED17_4_4	✓	✓	✓	✓		S0034
508 RXH Hybrid4	Engine	MED17_4_4EP8	✓	✓	✓	✓		
508 RXH Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		
508 RXH Hybrid4	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
508 RXH Hybrid4	ABS	ABS81	✓	✓	✓	✓	✓	S0039,S0035
508 RXH Hybrid4	ABS	ESP81	✓	✓	✓	✓	✓	S0039,S0035,S0038
508 RXH Hybrid4	BSI		✓	✓	✓	✓		S0033
508 RXH Hybrid4	Airbag		✓	✓	✓	✓		
508 RXH Hybrid4	Instrument panel		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Air Conditioning		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Power steering electric pump unit		✓	✓	✓	✓	✓	

508 RXH Hybrid4	Under inflation detection		✓	✓	✓	✓		
508 RXH Hybrid4	Battery charge status unit		✓	✓	✓	✓		
508 RXH Hybrid4	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Engine relay unit		✓	✓	✓	✓		
508 RXH Hybrid4	Trailer relay unit		✓	✓	✓	✓		
508 RXH Hybrid4	Parking aid		✓	✓	✓	✓		
508 RXH Hybrid4	Anti theft alarm		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 RXH Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 RXH Hybrid4	Telematics unit		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Active damper electronic unit		✓	✓	✓	✓		
508 RXH Hybrid4	Multiplexed control panel		✓	✓	✓	✓		
508 RXH Hybrid4	Matrix screen integral to the instrument panel		✓	✓	✓	✓		
508 RXH Hybrid4	Radio		✓	✓	✓	✓	✓	

508 RXH Hybrid4	Radio amplifier		✓	✓	✓	✓		
508 RXH Hybrid4	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Motorised Boot ECU		✓	✓	✓	✓		
508 RXH Hybrid4	High Head Vision		✓	✓	✓	✓		
508 RXH Hybrid4	Electric secondary brake		✓	✓	✓	✓		S0038
508 RXH Hybrid4	Main beams assistant ECU		✓	✓	✓	✓		
508 RXH Hybrid4	Electric steering lock		✓	✓	✓	✓		
4008	Engine	MIVEC	✓	✓	✓	✓	✓	
4008	Engine	CMM 4A92	✓	✓	✓	✓	✓	
4008	Engine	HDI 4N13	✓	✓	✓	✓	✓	
4008	Engine	HDI SID807 J3J4	✓	✓	✓	✓	✓	
4008	AT		✓	✓	✓	✓		
4008	ABS	ABS 4X4	✓	✓	✓	✓		



4008	ABS	ESP 4X4	✓	✓	✓	✓	✓	
4008	SRS		✓	✓	✓	✓	✓	
4008	Air conditioning		✓	✓	✓	✓	✓	
4008	Alarm		✓	✓	✓	✓		
4008	BSI		✓	✓	✓	✓	✓	
4008	Instrument panel		✓	✓	✓	✓	✓	S0033
4008	Directional headlamps		✓	✓	✓	✓	✓	
4008	Driver's door module		✓	✓	✓	✓		
4008	Power steering		✓	✓	✓	✓		
4008	Immobiliser	KOS	✓	✓	✓	✓	✓	
4008	Immobiliser	WCM	✓	✓	✓	✓		
4008	Parking assistance		✓	✓	✓	✓		
4008	Radio		✓	✓	✓	✓		
4008	DARA(STT MMC)		✓	✓	✓	✓		

4008	Navigation		✓	✓	✓	✓		
4008	Rain Sensor		✓	✓	✓	✓		
4008	Rear final drive piloted clutch		✓	✓	✓	✓		
4008	Steering wheel angle sensor		✓	✓	✓	✓		S0035
2008	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
2008	Engine	V46	✓	✓	✓	✓		
2008	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
2008	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
2008	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
2008	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
2008	Engine	VD46	✓	✓	✓	✓		
2008	Engine	MED17_4_4	✓	✓	✓	✓		S0034
2008	ABS or ESP ECU	ABS MK100	✓	✓	✓	✓	✓	S0039
2008	ABS or ESP ECU	ESPMK100	✓	✓	✓	✓	✓	S0039

2008	Gearbox	CFC300P	√	√	√	√	√	
2008	Gearbox	BVMP	√	√	√	√		
2008	Gearbox	BVA AL4	√	√	√	√	√	
2008	Gearbox	MAPS_UDS	√	√	√	√		
2008	Air bag		√	√	√	√		
2008	BSI		√	√	√	√		S0033
2008	Independent telematic unit(BTA)		√	√	√	√		
2008	Matrix screen integral to the instrument panel		√	√	√	√		
2008	Parking aid		√	√	√	√		
2008	Switch module under the steering wheel		√	√	√	√	√	
2008	Electric power steering		√	√	√	√		
2008	Rain sunlight sensor		√	√	√	√		
2008	Controls on the steering wheel		√	√	√	√		
2008	Electric steering lock		√	√	√	√		

2008	Air conditioning		✓	✓	✓	✓		
2008	Instrument panel		✓	✓	✓	✓	✓	
2008	Multiplexed control panel		✓	✓	✓	✓		
308S	Engine	V46 52	✓	✓	✓	✓		
308S	Engine	VD46	✓	✓	✓	✓		
308S	Engine	V46_32 Y2	✓	✓	✓	✓		
308S	Engine	MED17_4_4	✓	✓	✓	✓		S0034
308S	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
308S	ABS or ESP ECU	ESP 90	✓	✓	✓	✓		S0035,S0038,S0039
308S	Air bag		✓	✓	✓	✓		
308S	Instrument Panel		✓	✓	✓	✓		
308S	BSI		✓	✓	✓	✓		S0033
308S	AC CLIM		✓	✓	✓	✓		
308S	Alarm	ALARME	✓	✓	✓	✓	✓	

308S	Alarm	LIN ALARM	√	√	√	√	√	
308S	Power steering		√	√	√	√		
308S	Steering Wheel Switching Module		√	√	√	√		
308S	Driver's Seat Memory Unit		√	√	√	√	√	
308S	Headlamp Height Corrector		√	√	√	√	√	
308S	Parking Aid(AAS)		√	√	√	√		
308S	Cd player		√	√	√	√		
308S	Engine relay unit		√	√	√	√		
308S	Control panel dot matrix display		√	√	√	√		
308S	Multi function display	EMF_C_UDS	√	√	√	√		
308S	RADIO	AUTORADIO	√	√	√	√	√	
308S	RADIO	RD43	√	√	√	√		
308S	RADIO	RD45	√	√	√	√	√	
308S	Rain Sensor		√	√	√	√		

308S	Multiplexed control panel	FMUX	✓	✓	✓	✓		
308S	Service module		✓	✓	✓	✓		
308S	Controls on the steering wheel		✓	✓	✓	✓		
308S	Touch screen		✓	✓	✓	✓		
308S	Telematics		✓	✓	✓	✓		
308S	Voltage stabilizing device		✓	✓	✓	✓		
308S	Electronic key reader		✓	✓	✓	✓		
308S	Electric steering lock		✓	✓	✓	✓		
308S	Telematics unit		✓	✓	✓	✓		
308(T9)	Engine	5FV MED 17.4.2 EURO 5	✓	✓	✓	✓	✓	
308(T9)	Engine	DCM6.2 DW10FD TED4 - 150CV	✓	✓	✓	✓	✓	
308(T9)	Engine	HDI_SID807_BR2	✓	✓	✓	✓	✓	
308(T9)	Engine	MED17_4_4	✓	✓	✓	✓		S0034
308(T9)	Engine	9HP EDC17C10_BR2	✓	✓	✓	✓	✓	

308(T9)	Engine	MEVD17_4_4	√	√	√	√		
308(T9)	Engine	VD46	√	√	√	√		
308(T9)	Engine	V46_21	√	√	√	√		
308(T9)	Engine	EDC17C60	√	√	√	√		
308(T9)	Gearbox ECU	BVA_AM6_AT6_UDS	√	√	√	√		
308(T9)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035,S0038,S0039
308(T9)	Air bag	RBG_UDS	√	√	√	√		
308(T9)	Instrument Panel		√	√	√	√		
308(T9)	BSI		√	√	√	√		S0033
308(T9)	AC CLIM		√	√	√	√		
308(T9)	Alarm	SIR	√	√	√	√		
308(T9)	Power steering		√	√	√	√		
308(T9)	Steering Wheel Switching Module	COM2008P	√	√	√	√		
308(T9)	Steering Wheel Switching Module	HDC	√	√	√	√	√	

308(T9)	Driver's Seat Memory Unit		√	√	√	√	√	
308(T9)	Display	EMF_C_UDS	√	√	√	√		
308(T9)	Display	MULTIFUNCTION SCREEN WITH PIXELS(C-)	√	√	√	√		
308(T9)	Display	EMF_DGT_UDS	√	√	√	√		
308(T9)	Headlamp height adjuster/directional headlamp	LADCT	√	√	√	√	√	
308(T9)	External CD player	CDE	√	√	√	√	√	
308(T9)	Electronic key reader	LCE	√	√	√	√		
308(T9)	Electric steering lock	AVE	√	√	√	√		
308(T9)	Diesel Additive Function	PADDGO_INERGY	√	√	√	√		
308(T9)	Telematics unit	SMEG_PLUS	√	√	√	√	√	
308(T9)	Vehicle distance assistance system	ARTIV_UDS	√	√	√	√		
308(T9)	Controls on the steering wheel	VCI	√	√	√	√		
308(T9)	Touch screen	EMF_DGT_UDS	√	√	√	√		
308(T9)	Rain Sensor	CDPL_UDS_HELLA	√	√	√	√		



308(T9)	Parking Aid(AAS)	AAS_UDS	√	√	√	√		
308(T9)	Audio amplifier	AMPLI_AUDIO	√	√	√	√		
308(T9)	Multiplexed control panel	FMUX	√	√	√	√		
308(T9)	Radio telephone transceiver control unit	CRT_UDS_KOSTAL	√	√	√	√		
308(T9)	Radio	RD45	√	√	√	√		
308(T9)	Matrix screen integral to the instrument panel	MATT_C_2010	√	√	√	√		
308(T9)	Voltage stabilizing device	DMTR	√	√	√	√		
408(T93)	Engine	V46 52	√	√	√	√		
408(T93)	Engine	VD46	√	√	√	√		
408(T93)	Engine	V46_32 Y2	√	√	√	√		
408(T93)	Engine	MED17_4_4	√	√	√	√		S0034
408(T93)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035,S0038,S0039
408(T93)	Gearbox ECU	BVA_AM6_AT6_UDS	√	√	√	√		
408(T93)	Telematics		√	√	√	√	√	

408(T93)	Air bag		√	√	√	√		
408(T93)	Radio telephone transceiver control unit		√	√	√	√		
408(T93)	Power steering		√	√	√	√		
408(T93)	Instrument Panel		√	√	√	√		
408(T93)	Rain Sensor		√	√	√	√		
408(T93)	Multiplexed control panel	FMUX	√	√	√	√		
408(T93)	Driver's Seat Memory Unit		√	√	√	√	√	
408(T93)	Matrix screen integral to the instrument panel		√	√	√	√		
408(T93)	Electronic key reader		√	√	√	√		
408(T93)	Electric steering lock		√	√	√	√		
408(T93)	Voltage stabilizing device		√	√	√	√		
408(T93)	Radio		√	√	√	√		
408(T93)	Steering Wheel Switching Module	COM2008P	√	√	√	√		
408(T93)	Steering Wheel Switching Module	HDC	√	√	√	√	√	

408(T93)	Headlamp height adjuster/directional headlamp	LADCT	√	√	√	√	√	
408(T93)	Parking Aid(AAS)	AAS_UDS	√	√	√	√		
408(T93)	Display	EMF_C_UDS	√	√	√	√		
408(T93)	Display	EMF_A_UDS	√	√	√	√		
408(T93)	Display	Touch screen	√	√	√	√		
408(T93)	AC CLIM		√	√	√	√		
408(T93)	Touch screen		√	√	√	√		
408(T93)	Alarm	Alarm	√	√	√	√	√	
408(T93)	Controls on the steering wheel		√	√	√	√		
408(T93)	BSI	BSI 2010	√	√	√	√		S0033
3008(P48)	Engine	DCM6.2 DW10FD TED4 - 150CV	√	√	√	√	√	
3008(P48)	Engine	MED17_4_4	√	√	√	√		S0034
3008(P48)	Engine	EDC17C60	√	√	√	√		
3008(P48)	Engine	VD46	√	√	√	√		

3008(P48)	Engine	MED17_4_4EP8	√	√	√	√		
3008(P48)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035,S0039,S0038
3008(P48)	Gearbox ECU	BVA_AM6_AT6_UDS	√	√	√	√		
3008(P48)	Air bag		√	√	√	√		
3008(P48)	Display	EMF_C_UDS	√	√	√	√		
3008(P48)	Steering Wheel Switching Module	COM2008P	√	√	√	√	√	
3008(P48)	Headlamp height adjuster/directional headlamp	LADCT	√	√	√	√	√	
3008(P48)	External CD player	CDE	√	√	√	√	√	
3008(P48)	Driver's door control panel	PDPC_UDS	√	√	√	√		
3008(P48)	Driver's door control panel	PDPC	√	√	√	√	√	
3008(P48)	Power steering	DAE_BVH2	√	√	√	√		
3008(P48)	Electric steering lock	AVE	√	√	√	√		
3008(P48)	Vehicle distance assistance system	ARTIV_UDS	√	√	√	√		
3008(P48)	AC CLIM	BCC	√	√	√	√		

3008(P48)	Controls on the steering wheel	VCI	√	√	√	√		
3008(P48)	Rain Sensor	CDPL_UDS_HELLA	√	√	√	√		
3008(P48)	Parking Aid(AAS)	AAS_UDS	√	√	√	√		
3008(P48)	Audio amplifier	AMPLI_AUDIO	√	√	√	√		
3008(P48)	Multiplexed control panel	FMUX	√	√	√	√		
3008(P48)	ALARM	SIR	√	√	√	√		
3008(P48)	Instrument Panel	COMBINE_UDS	√	√	√	√	√	
3008(P48)	Instrument Panel	CIROCCO	√	√	√	√		
3008(P48)	Voltage stabilizing device	DMTR	√	√	√	√		
3008(P48)	Body control module	VERINS_MOTORISES	√	√	√	√		
3008(P48)	Automatic Gearbox Electric Control Unit	COMELEC2	√	√	√	√		
3008(P48)	BSI	BSI 2010	√	√	√	√		S0033
4008(China)	Engine	DCM6.2 DW10FD TED4 - 150CV	√	√	√	√	√	
4008(China)	Engine	MED17_4_4	√	√	√	√		S0034

4008(China)	Engine	EDC17C60	√	√	√	√		
4008(China)	Engine	VD46	√	√	√	√		
4008(China)	Engine	MED17_4_4EP8	√	√	√	√		
4008(China)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035,S0039,S0038
4008(China)	Gearbox ECU	BVA_AM6_AT6_UDS	√	√	√	√		
4008(China)	Air bag		√	√	√	√		
4008(China)	Display	EMF_C_UDS	√	√	√	√		
4008(China)	Steering Wheel Switching Module	COM2008P	√	√	√	√	√	
4008(China)	Headlamp height adjuster/directional headlamp	LADCT	√	√	√	√	√	
4008(China)	External CD player	CDE	√	√	√	√	√	
4008(China)	Driver's door control panel	PDPC_UDS	√	√	√	√		
4008(China)	Driver's door control panel	PDPC	√	√	√	√	√	
4008(China)	Power steering	DAE_BVH2	√	√	√	√		
4008(China)	Electric steering lock	AVE	√	√	√	√		

4008(China)	Vehicle distance assistance system	ARTIV_UDS	√	√	√	√		
4008(China)	AC CLIM	BCC	√	√	√	√		
4008(China)	Controls on the steering wheel	VCI	√	√	√	√		
4008(China)	Rain Sensor	CDPL_UDS_HELLA	√	√	√	√		
4008(China)	Parking Aid(AAS)	AAS_UDS	√	√	√	√		
4008(China)	Audio amplifier	AMPLI_AUDIO	√	√	√	√		
4008(China)	Multiplexed control panel	FMUX	√	√	√	√		
4008(China)	ALARM	SIR	√	√	√	√		
4008(China)	Instrument Panel	COMBINE_UDS	√	√	√	√	√	
4008(China)	Instrument Panel	CIROCCO	√	√	√	√		
4008(China)	Voltage stabilizing device	DMTR	√	√	√	√		
4008(China)	Body control module	VERINS_MOTORISES	√	√	√	√		
4008(China)	Automatic Gearbox Electric Control Unit	COMELEC2	√	√	√	√		
4008(China)	BSI	BSI 2010	√	√	√	√		S0033

5008(P84)	Engine	DCM6.2 DW10FD TED4 - 150CV	✓	✓	✓	✓	✓	
5008(P84)	Engine	MED17_4_4	✓	✓	✓	✓		S0034
5008(P84)	Engine	EDC17C60	✓	✓	✓	✓		
5008(P84)	Engine	VD46	✓	✓	✓	✓		
5008(P84)	Engine	MED17_4_4EP8	✓	✓	✓	✓		
5008(P84)	ABS or ESP ECU	ESP 90	✓	✓	✓	✓		S0035,S0039,S0038
5008(P84)	Gearbox ECU	BVA_AM6_AT6_UDS	✓	✓	✓	✓		
5008(P84)	Air bag		✓	✓	✓	✓		
5008(P84)	Display	EMF_C_UDS	✓	✓	✓	✓		
5008(P84)	Steering Wheel Switching Module	COM2008P	✓	✓	✓	✓	✓	
5008(P84)	Headlamp height adjuster/directional headlamp	LADCT	✓	✓	✓	✓	✓	
5008(P84)	External CD player	CDE	✓	✓	✓	✓	✓	
5008(P84)	Driver's door control panel	PDPC_UDS	✓	✓	✓	✓		
5008(P84)	Driver's door control panel	PDPC	✓	✓	✓	✓	✓	



5008(P84)	Power steering	DAE_BVH2	√	√	√	√		
5008(P84)	Electric steering lock	AVE	√	√	√	√		
5008(P84)	Vehicle distance assistance system	ARTIV_UDS	√	√	√	√		
5008(P84)	AC CLIM	BCC	√	√	√	√		
5008(P84)	Controls on the steering wheel	VCI	√	√	√	√		
5008(P84)	Rain Sensor	CDPL_UDS_HELLA	√	√	√	√		
5008(P84)	Parking Aid(AAS)	AAS_UDS	√	√	√	√		
5008(P84)	Audio amplifier	AMPLI_AUDIO	√	√	√	√		
5008(P84)	Multiplexed control panel	FMUX	√	√	√	√		
5008(P84)	ALARM	SIR	√	√	√	√		
5008(P84)	Instrument Panel	COMBINE_UDS	√	√	√	√	√	
5008(P84)	Instrument Panel	CIROCCO	√	√	√	√		
5008(P84)	Voltage stabilizing device	DMTR	√	√	√	√		
5008(P84)	Body control module	VERINS_MOTORISES	√	√	√	√		

5008(P84)	Automatic Gearbox Electric Control Unit	COMELEC2	√	√	√	√		
5008(P84)	BSI	BSI 2010	√	√	√	√		S0033
308(TX9)	Engine	MED17_4_4	√	√	√	√		S0034
308(TX9)	Engine	VD46	√	√	√	√		
308(TX9)	Engine	V46 52	√	√	√	√		
308(TX9)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035,S0039,S0038
308(TX9)	AT BVA AL	BVA_AM6_AT6_UDS	√	√	√	√		
308(TX9)	Airbag	RBG_UDS	√	√	√	√		
308(TX9)	AutoRadio		√	√	√	√	√	
308(TX9)	Parking Aid(AAS)	4 parking assist sensor	√	√	√	√		
308(TX9)	Instrument Panel	COMBINE_UDS	√	√	√	√		
308(TX9)	Steering Wheel Switching Module	COM2008P	√	√	√	√	√	
308(TX9)	Multi function display		√	√	√	√		
308(TX9)	Power steering electric pump unit	DAE_BVH2	√	√	√	√		



## Special Functions List

No.	Functions Name	System Name
S0033	Maintenance and return to zero	BSI
S0033	Maintenance and return to zero	BSI-BSI 2010
S0033	Maintenance and return to zero	Instrument Panel
S0034	Throttle matching	Engine-1.6 16v BOSCH Motronic ME 7.4.5[NFR]
S0034	Throttle matching	Engine-BOSCH ME7.4.5
S0034	Throttle matching	Engine-BOSCH ME749
S0034	Throttle matching	Engine-EMV17 4 2
S0034	Throttle matching	Engine-J34P
S0034	Throttle matching	Engine-KFU MM6LP
S0034	Throttle matching	Engine-KFU MM6LPC
S0034	Throttle matching	Engine-KFV J34P
S0034	Throttle matching	Engine-KFV S2000PM2
S0034	Throttle matching	Engine-ME744
S0034	Throttle matching	Engine-ME745
S0034	Throttle matching	Engine-ME745 EC5
S0034	Throttle matching	Engine-ME747
S0034	Throttle matching	Engine-ME749

S0034	Throttle matching	Engine-ME749 BIO FLEX
S0034	Throttle matching	Engine-ME749 EC5
S0034	Throttle matching	Engine-MED17 4 2
S0034	Throttle matching	Engine-MED17 4 EURO4
S0034	Throttle matching	Engine-MED17 4 EURO5
S0034	Throttle matching	Engine-MED17_4_4
S0034	Throttle matching	Engine-MEV17 4 2
S0034	Throttle matching	Engine-MEV17 4 EURO4
S0034	Throttle matching	Engine-MEV17 4 EURO5
S0034	Throttle matching	Engine-MEV17.4
S0034	Throttle matching	Engine-MEVD17 4 2
S0034	Throttle matching	Engine-MM6KP
S0034	Throttle matching	Engine-MM6KP bio
S0034	Throttle matching	Engine-MM6KP Bio Flex1
S0034	Throttle matching	Engine-MM6KP Bio Flex2
S0034	Throttle matching	Engine-MM6KP BioFlex
S0034	Throttle matching	Engine-MM6LP
S0034	Throttle matching	Engine-MM6LPC
S0034	Throttle matching	Engine-N6A_ME749_BIO_FLEX
S0034	Throttle matching	Engine-NFU BOSCH ME745
S0034	Throttle matching	Engine-NFU ME744
S0034	Throttle matching	Engine-NFU OR N6A ME749
S0034	Throttle matching	Engine-RFH MM6KP
S0034	Throttle matching	Engine-RFJ MM6LPB
S0034	Throttle matching	Engine-RFK MM6LP
S0034	Throttle matching	Engine-RFN MM6LP
S0034	Throttle matching	Engine-V341
S0034	Throttle matching	Service Module (RASTREADOR)
S0035	Steering angle reset	ABS or ESP ECU-ABS 81
S0035	Steering angle reset	ABS or ESP ECU-ABS8 BOSCH
S0035	Steering angle reset	ABS or ESP ECU-ESP
S0035	Steering angle reset	ABS or ESP ECU-ESP 90
S0035	Steering angle reset	ABS or ESP ECU-ESP MK60
S0035	Steering angle reset	ABS or ESP ECU-ESP8 BOSCH

S0035	Steering angle reset	ABS or ESP ECU-ESP81
S0035	Steering angle reset	ABS or ESP ECU-ESPMK60 0
S0035	Steering angle reset	ABS-81 ESP
S0035	Steering angle reset	ABS-ABS 8.1
S0035	Steering angle reset	ABS-ABS ESP8 0
S0035	Steering angle reset	ABS-ABS8
S0035	Steering angle reset	ABS-ABS81
S0035	Steering angle reset	ABS-BOSCH ABS 8.1
S0035	Steering angle reset	ABS-ESP 8.1
S0035	Steering angle reset	ABS-ESP 81
S0035	Steering angle reset	ABS-ESP8
S0035	Steering angle reset	ABS-ESP8 BOSCH
S0035	Steering angle reset	ABS-ESP81
S0035	Steering angle reset	ABS-ESP81 BOSCH
S0035	Steering angle reset	ABS/ESP
S0035	Steering angle reset	ABS/ESP-ESP BOSCH57
S0035	Steering angle reset	ABS/ESP-ESP BOSCH8
S0035	Steering angle reset	ABS/ESP-ESP BOSCH8 KwpECU
S0035	Steering angle reset	ABS/ESP-ESP MK60 0
S0035	Steering angle reset	ABS/ESP-ESP8.1
S0035	Steering angle reset	Flywheel Angle Sensor
S0035	Steering angle reset	Power steering
S0035	Steering angle reset	Steering wheel angle sensor
S0036	Injector code	Engine-9HU EDC16C3
S0036	Injector code	Engine-9HV BOSCH EDC16C3
S0036	Injector code	Engine-DCM3.4
S0036	Injector code	Engine-DCM3.5 BR2
S0036	Injector code	Engine-DCM3.5 RHE/RHH
S0036	Injector code	Engine-DCM34
S0036	Injector code	Engine-DCM35
S0036	Injector code	Engine-DCM35 BR2
S0036	Injector code	Engine-DCM35 HY
S0036	Injector code	Engine-EDC16C3
S0036	Injector code	Engine-EDC16C3 (CAN)

S0036	Injector code	Engine-EDC16C3DV4
S0036	Injector code	Engine-EDC17C10
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17CP11
S0036	Injector code	Engine-RHH DCM3.5
S0036	Injector code	Engine-RHH DW10CTED4-163CV
S0037	DPF regeneration	Engine-4HK EDC16CP39
S0037	DPF regeneration	Engine-4HN EDC16CP39
S0037	DPF regeneration	Engine-BOSCH EDC16C3
S0037	DPF regeneration	Engine-DCM3.4
S0037	DPF regeneration	Engine-DCM3.5 BR2
S0037	DPF regeneration	Engine-DCM3.5 RHE/RHH
S0037	DPF regeneration	Engine-DCM34
S0037	DPF regeneration	Engine-DCM35
S0037	DPF regeneration	Engine-DCM35 BR2
S0037	DPF regeneration	Engine-DCM35 HY
S0037	DPF regeneration	Engine-EDC16C3
S0037	DPF regeneration	Engine-EDC16C3 (CAN)
S0037	DPF regeneration	Engine-EDC16CP39
S0037	DPF regeneration	Engine-EDC17C10
S0037	DPF regeneration	Engine-EDC17C10 BR2
S0037	DPF regeneration	Engine-EDC17C10 BR2
S0037	DPF regeneration	Engine-EDC17C60
S0037	DPF regeneration	Engine-EDC17CP11
S0037	DPF regeneration	Engine-EDC17CP42
S0037	DPF regeneration	Engine-EDC17CP52
S0037	DPF regeneration	Engine-EDC17CP52 UDS
S0037	DPF regeneration	Engine-HDI SID803A
S0037	DPF regeneration	Engine-HDI SID807
S0037	DPF regeneration	Engine-HDI SID807 BR2
S0037	DPF regeneration	Engine-HDI SID803
S0037	DPF regeneration	Engine-RHH DCM3.5
S0037	DPF regeneration	Engine-RHH DW10CTED4-163CV

S0037	DPF regeneration	Engine-SID201
S0037	DPF regeneration	Engine-SID803
S0037	DPF regeneration	Engine-SID807
S0037	DPF regeneration	Engine-SID807 BR2
S0038	Brake pad reset	ABS or ESP ECU-ESP 90
S0038	Brake pad reset	ABS or ESP ECU-ESP81
S0038	Brake pad reset	ABS-ESP81
S0038	Brake pad reset	Electric parking brake
S0038	Brake pad reset	Electric secondary brake
S0039	Exhaust	ABS or ESP ECU
S0039	Exhaust	ABS or ESP ECU-ABS 81
S0039	Exhaust	ABS or ESP ECU-ABS MK100
S0039	Exhaust	ABS or ESP ECU-ABS MK70
S0039	Exhaust	ABS or ESP ECU-ABS MK70.1
S0039	Exhaust	ABS or ESP ECU-ABS8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ABS81
S0039	Exhaust	ABS or ESP ECU-ABSMK70 1
S0039	Exhaust	ABS or ESP ECU-ESP 90
S0039	Exhaust	ABS or ESP ECU-ESP MK60
S0039	Exhaust	ABS or ESP ECU-ESP8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ESP81
S0039	Exhaust	ABS or ESP ECU-ESPMK100
S0039	Exhaust	ABS or ESP ECU-ESPMK60 0
S0039	Exhaust	ABS-81 ESP
S0039	Exhaust	ABS-ABS 8.1
S0039	Exhaust	ABS-ABS ABS8 0
S0039	Exhaust	ABS-ABS ASR8 0
S0039	Exhaust	ABS-ABS ESP8 0
S0039	Exhaust	ABS-ABS MK100
S0039	Exhaust	ABS-ABS8
S0039	Exhaust	ABS-ABS81
S0039	Exhaust	ABS-BOSCH ABS 8.1
S0039	Exhaust	ABS-ESP 8.1
S0039	Exhaust	ABS-ESP8



S0039	Exhaust	ABS-ESP8 BOSCH
S0039	Exhaust	ABS-ESP81
S0039	Exhaust	ABS-ESP81 BOSCH
S0039	Exhaust	ABS-ESPMK100
S0039	Exhaust	ABS/ESP
S0039	Exhaust	ABS/ESP-ABS8 BOSCH
S0039	Exhaust	ABS/ESP-ABS8.1
S0039	Exhaust	ABS/ESP-ESP BOC SH8
S0039	Exhaust	ABS/ESP-ESP BOSCH57
S0039	Exhaust	ABS/ESP-ESP BOSCH8
S0039	Exhaust	ABS/ESP-ESP BOSCH8 KwpECU
S0039	Exhaust	ABS/ESP-ESP MK60 0
S0039	Exhaust	ABS/ESP-ESP8.1
S0039	Exhaust	ABS/ESP-MK70.1
S003A	Battery matching	Battery charge status unit-BECB
S003A	Battery matching	Battery charge status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit
S003A	Battery matching	Battery charge status unit-BECB
S003A	Battery matching	Battery charge status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit-BECB GEN2
S0040	Adaptive initialization	Engine-ME745
S0041	Replace the throttle body , Accelerator pedal sensor , Ejector , Oxygen	Engine-ME745
S0042	Replace ECU	Engine-ME745